

80000805 OX-029导靴(无油壶支架,按图装配)

16mm 灰色RAL7037 全英文 上海现代

技术要求 (NOTE):

1. 将导靴支撑(H03)放入框架(H01, H02)槽中, 然后用固定板(H04)将之固定。
PUT THE GUIDE SHOE SUPPORT INTO FRAMES(H01, H02)
GROOVE, THEN USE THE FIXING PLATE TO FIX.
 2. 用螺栓(H10)和调节螺母(H09)和螺母(H11)锁紧导靴支撑(H03),
锁紧力矩: 47.0~56.8kg·cm
FIXING BRAKET ASSY(H03) WITH BOLT(H10), NUT(H09)
AND NUT(H11) LOCKING TORQUE: 47.0~56.8KG·CM

装配要求 (ASSEMBLY REQUIREMENTS):

1. 在滑动导轨出厂前预先调节好,见*1处调节到5mm时将(H10, H11)固定。
PRESET SLIDING GUIDE SHOES BEFORE THEY GO OUT, SEE THE *1, ADJUSTED TO 5MM, TO FIX (H10, H11).
 2. 以上调节好后,确保*2处的尺寸在1.5~2mm之内,如不在范围内则重新调节。
ENSURE THE *2 SIZE WITHIN 1.5~2MM IF NOT IN SCOPE, READJUSTING.

[G] NO.	A1	A2	A3	t	导轨 RAIL	备注 (REMARK)
G01	140	90	60	10	8K, T75	OX-029
G02	140	90	60	16/15.88	13K, T82-3 TD6-2 5 T89-1	